

智能锁网关

G2

使用说明

智能锁网关 G2

产品型号	G2
尺寸	70mm x 70mm x 26mm
网络	WiFi 2.4G
IEEE标准	802.11 b/g/n
电源接口	Type-C USB
电源输入	DC 5V/500mA

灯光状态说明




设备通电后，状态灯：


- 红蓝指示灯交替闪烁：准备状态，当前可被 APP 添加绑定；
- 蓝色：表示正常工作状态，不可被绑定；
- 红色：网络不畅，无法与服务器通讯；

通过APP添加网关

1 打开 APP



2 点击屏幕左上角的“☰”



3 下拉列表中选择 [网关]




4 选择 [G2]



6 点击“+”



5 给网关接通电源，红蓝两色灯交替闪烁



7 配置网络



8 选择正确的网络并输入密码



9 添加完成

⚠ 注意：如果超时未绑定成功，请断电重新尝试

产品保修说明

- 自购买产品之日起 7 日内，若产品出现非人为损坏的质量问题，可以选择按购买价格退货或更换同型号产品；
- 自购买产品之日起至第十五日内，若产品出现非人为损坏的质量问题，可以选择免费更换同型号的产品；
- 自购买产品之日起 12 个月内，若产品出现非人为损坏的性能故障，提供免费保修服务。

GATEWAY

G2

User Manual

GATEWAY G2

Model :	G2
Dimensions :	70mm x 70mm x 26mm
Network :	WiFi 2.4G
IEEE standard :	802.11 b/g/n
Power interface :	Type-C USB
Power input :	DC 5V/500mA

Light Status




When the gateway is powered on:

- Light flashes alternately in red and blue: Stand-by mode, ready for pairing
- Blue light: Working mode
- Red light: Network failure

Pair the Gateway with APP

1 Activate the APP




2 Press “☰”




3 Select [Gateway]




4 Select [G2]



5 Plug in the gateway and power it on, while the light flashes alternately in red and blue



6 Press “+” sign



7 Add Gateway



8 Select the network and fill in the password



9 Add complete

⚠ Notice: If times out, please power off and try it again.

Limited Warranty

1. For any defect in material and workmanship, the original purchaser of the product

- 1) Can return or ask for a replacement within 7 invoice days.
- 2) Can ask for a replacement within 15 invoice days.
- 3) Can ask for free repair in 365 invoice days.

2. This warranty does not cover defects caused by modification, alteration, misuse or physical abuse of the product.